



Step 1: Lay receptacle on a clean area, with the decal side facing outward.

