

**FLUORESCENT LAMPHOLDER  
WIRING INSTALLATION INSTRUCTIONS**

**NOTICE:** For installation by a qualified electrician in accordance with national and local electrical codes and the following instructions.

Cat. No.	Strip Length	Wire Size
RL305, RL306, RL310, RL311, RL320, RL325, RL325A & RL523B	3/8"	No. 18 AWG (See Notes)

1. Leads should be inserted into the openings provided in the base of each lampholder until the insulation touches the lip of the lead opening of the lampholder body.
2. Specified strip lengths permit wire insulation to butt against "wire fast" entrance holes. Pull back slightly on the inserted lead(s) to lock wire in place.
3. The leads employed should be twisted and solder dipped stranded copper conductor, solid copper conductor, or top coat bonded or fused stranded copper conductor.
4. **DO NOT INSERT LEADS IN THE INSIDE SLOTS PROVIDED FOR RELEASE OF WIRES.**

Wiring Device-Kellems  
Hubbell Incorporated (Delaware)  
Shelton, CT 06484, 1-800-288-6000  
[www.hubbell-wiring.com](http://www.hubbell-wiring.com)  
PD2458 Rev. 06/11